


HOW TO SET YOUR AVALON TALKING CALENDAR WATCH INSTRUCTIONS SHEET



The above diagram represents a watch with four buttons labeled as follows:
S1 = top right button, S2 = lower right button, S3 = top left button, S4 = lower left button

I. Button Functions:

- A. Crown – Used to set Analog Time
- B. S1 – Press to activate voice saying time
- C. S2 – Use only when setting time, date, alarm, and chime functions
- D. S3 – Press to activate voice saying day, date and year
- E. S4 – Use only when setting time, date, alarm and chime functions

II. Setting Instructions for Analog Time:

- A. Gently pull crown out until you feel a click
- B. Turn crown to set hour and minute hands
- C. Push crown back in to set time

III. Setting Instructions for Talking Time, Date, Alarm and Chime:

- A. Press “S4” button to navigate through the different functions to set
- B. Once you reach the desired function, then use the “S2” button to adjust

Example:

To set the time, press “S4” until you hear “Time Hour Setting”, then press “S2” to move to the desired hour. Press “S4” again to hear “Time Minute Setting”, then press “S2” to move to the desired minute. This same process is used to set all functions.

Check our selection of Talking Watches at
www.assistech.com/low_vision/talkingwatches.htm